

CREW: 163 WORK ORDER TYPE: MODIFICATIONS

01-19846-21

ISSUE DATE 01/06/11

Page 1 Of 2

Originator : KEVIN MILLER Schedule Date :
Planner : KEVIN MILLER Priority : 3C
Drawing No : 1TGA-M2079 Clearance : NO
Equip No/Cat: 1TGA--1 1 Tag Request :
Project ID : 1TGA-TRB-1 Text ID :
Shutdown : U Unit Frequency : NOT SCHEDULED
Ref No : Last Reading : No Reading

Date Completed: _____ Failure Code: _____
Completed By : _____ Signature : _____
Accepted By : _____ Signature : _____

**** Delay Codes Legend ****
W=Whse C=CrSp T=Tag TL=Tool P=Plan
**** Record Time Daily ****
Delays

Step	Job Scope	MN	DY	Safety and Additional Information	Emp No	Date	Hours	Code/Hrs
1	PULL TWO NEW THERMOCOUPLE CABLES REQUIRED BY ALSTOM FOR THE NEW HIGH PRESSURE TURBINE.	2	1	***** SAFETY / ENVIRONMENTAL REQUIREMENTS: A. ALWAYS WEAR THE REQUIRED PPE. B. NO WORK CARD REQUIRED. TERMINATIONS WILL BE BY OTHERS. C. TIE OFF WHEN WORKING IN THE CABLE TRAY AREA. ***** ADDITIONAL INFORMATION: A. OBTAIN 1000' OF THERMOCOUPLE EXTENSION CABLE STAGED AT THE WAREHOUSE ALONG WITH A J-BOX AND 50' OF 1" PIPE PLUS OTHER MISC ITEMS LISTED ON THE PARTS PAGE.				
***** JOB SCOPE: 1. THIS WAS DONE LAST OUTAGE BY SCHENA AND ASSOCIATES. PLEASE DUPLICATE WHAT WAS DONE THERE WITH MOUNTING THE BOX, RUNNING CONDUIT, AND PULLING BOTH CABLES TO THE CONTROL ROOM CABINETS. AT THIS WRITING I DON'T HAVE THE DRAWINGS FROM BILL MORGAN BUT THEY WILL BE AVAILABLE BY OUTAGE TIME. 2. INSTALL J-BOX ON THE NORTH SIDE OF THE HIGH PRESSURE HOOD AS DISCUSSED IN THE FIELD WALKDOWN. INSTALL CONDUIT FROM NEAREST TRAY. 3. TWO CABLES NEED TO BE PULLED INTO THE FIELD I/O CABINET (FOX) AND THE OTHER ENDS WILL BE TERMINATED ON THE TOP AND BOTTOM SHELL OF THE NEW TURBINE. PLEASE ROUTE CABLE AS YOU WISH BUT TRY TO STAY IN THE ELECTRONICS (SIGNAL) LEVEL CABLE TRAYS WHICH ARE LABELED 2TEC0023 FOR EXAMPLE. THE 'E' SIGNIFYING ELECTRONICS. 4. PLEASE WRITE DOWN THE ROUTE YOU TAKE AND RETURN WITH THE WORK ORDER SO I CAN ENTER THE CIRCUITS IN THE PROJECT DATABASE.								

**** IMPORTANT NOTICE ****
YOU ARE RESPONSIBLE FOR YOUR OWN SAFETY AND MUST ENSURE THAT THE REQUIRED PPE IS WORN FOR EVERY JOB YOU ARE DOING. IF YOU HAVE ANY QUESTIONS CONCERNING THE WORK RULES, SAFETY CODES, OR REQUIRED PPE, PLEASE CONTACT YOUR SUPERVISOR.

Job Feedback/Historical Notes:

01-19846-21^H

IP7_005533

** Work Order Parts List **

Part No	Description	PO/Req/SIR	Date Due	U/M	Reqd	Commit	Issued/Rcvd
-----	-----	-----	-----	---	-----	-----	-----
1 19933	BOX, JUNCTION	S 230928	01/01/03	EA	1	0	1
2 50618	ROD, ALLTHREAD	S 230928	01/01/03	EA	1	0	1
3 58168	CONDUIT, FLEXIBLE	S 230928	01/01/03	FT	10	0	10
4 58394	CONDUIT, RIGID	S 230928	01/01/03	PC	7	0	7
5 58396	CONDUIT, RIGID	S 230928*	01/01/03	PC	6	0	6
6 66161	CABLE, THERMOCOUPLE	S 230928*	01/01/03	FT	3280	0	3280

IP7_005534